

SENSOR PARTS FOR YOUR **KOMATSU** MINING MACHINES



Description	OEM No.	Application	Picture
Pressure Sensor	7861-93-1651	KOMATSU	
Pressure Sensor	7861-92-1610	KOMATSU	
Pressure Sensor	7861-93-1650 7861-93-1652	KOMATSU	
Pressure Sensor	7861-93-1812 7861-93-1811	KOMATSU	
Pressure Sensor	7861-93-1840	KOMATSU	
High Pressure Sensor	6754-72-1210 6754-72-1211 6754-72-1212	KOMATSU	
High Pressure Sensor	ND4990006160 N499000-6160	KOMATSU	
High Pressure Sensor	ND4990004441 499000-4441	KOMATSU	

Description	OEM No.	Application	Picture
Exhaust Pressure Sensor	6219-81-1961	KOMATSU	
Oil Pressure Switch	6744-81-4010	KOMATSU	
MAP Sensor	6754-81-2701	KOMATSU	
MAP Sensor	6261-81-1900	KOMATSU	
Manifold Pressure Sensor	6271-81-1910	KOMATSU	
Manifold Pressure Sensor	6216-84-9330 6216-84-9331	KOMATSU	
Pressure Switch	20Y0615190	KOMATSU	
Pressure Switch	6732-81-3111	KOMATSU	
Pressure Switch	206-06-61130	KOMATSU	

Description	OEM No.	Application	Picture
Pressure Switch	20Y0621710 20PS579-16	KOMATSU	
Pressure Sensor	208-06-71130	KOMATSU	
Speed Sensor	6261-81-2600	Komatsu	
Pressure Switch	421-43-22912 421-43-22911	Komatsu	
Pressure Switch	421-43-32922 421-43-32921	Komatsu	
Pressure Sensor	208-06-71140	Komatsu	
Pressure Sensor	6261-81-2700	Komatsu	



Description	OEM No.	Application	Picture
Temperature Sensor	7861-93-3320 7861-93-3380	KOMATSU	
Temperature Sensor	7861-92-3320	KOMATSU	
Temperature Sensor	7861-92-3380	KOMATSU	
Coolant Temperature Sensor	6261-81-6901	KOMATSU	
Air Temperature Sensor	6560-61-7300	KOMATSU	
Temperature Sensor	7861-93-3520	KOMATSU	
Position Sensor	ND949979-1300 8-97606943-0	KOMATSU	
Position Sensor	6261-81-2901	KOMATSU	

Description	OEM No.	Application	Picture
Position Sensor	6754-81-9200	KOMATSU	
Position Sensor	6217-81-9210 VH89411E0050 19311-78010 029600-0580 029600-0570	KOMATSU	
Speed Sensor	7861-93-2310 7861-93-2330	KOMATSU	
Speed Sensor	7861-92-2310	KOMATSU	





**CALL ONE OF OUR QUALIFIED SALES
REPRESENTATIVES TODAY
TO FIND OUT MORE**

011 5684215

QUOTES@CAPIPARTS.CO.ZA

WWW.CAPIPARTS.CO.ZA