

SENSOR PARTS FOR YOUR **CATERPILLAR®** MINING MACHINES



Description	OEM No.	Application	Picture
Pressure Sensor	224-4536 194-6726	CATERPILLAR	
Pressure Sensor	161-1705	CATERPILLAR	
Pressure Sensor	165-5183	CATERPILLAR	
Pressure Sensor	194-6722 161-9925 141-4119	CATERPILLAR	
Pressure Sensor	194-6725	CATERPILLAR	
Pressure Sensor	237-4894	CATERPILLAR	
Pressure Sensor	291-1265	CATERPILLAR	
Pressure Sensor	274-6721 278-5225	CATERPILLAR	
Pressure Sensor	194-6724 161-9929	CATERPILLAR	

Description	OEM No.	Application	Picture
Pressure Sensor	161-1703	CATERPILLAR	
Pressure Sensor	161-1704	CATERPILLAR	
Pressure Sensor	290-5825 163-8511	CATERPILLAR	
Pressure Sensor	274-6719 248-2167	CATERPILLAR	
Pressure Sensor	320-3062	CATERPILLAR	
Pressure Sensor	344-7389	CATERPILLAR	
Pressure Sensor	344-7390	CATERPILLAR	
Pressure Sensor	344-7391	CATERPILLAR	
Pressure Sensor	349-1178	CATERPILLAR	

Description	OEM No.	Application	Picture
Pressure Sensor	344-7392	CATERPILLAR	
Pressure Sensor	320-3064	CATERPILLAR	
Pressure Sensor	320-3065	CATERPILLAR	
Pressure Sensor	296-5270	CATERPILLAR	
Pressure Sensor	248-2169	CATERPILLAR	
Pressure Sensor	335-5321	CATERPILLAR	
Pressure Sensor	238-0118	CATERPILLAR	
Pressure Sensor	261-0420	CATERPILLAR	
Pressure Sensor	284-2728 248-2168	CATERPILLAR	

Description	OEM No.	Application	Picture
Pressure Sensor	194-6723	CATERPILLAR	
Pressure Sensor	161-9927 111-2351 121-2728 141-4120 3E6379	CATERPILLAR	
Pressure Sensor	305-6873	CATERPILLAR	
Pressure Sensor	260-2180	CATERPILLAR	
Pressure Sensor	274-6717	CATERPILLAR	
Pressure Sensor	274-6718 248-2165	CATERPILLAR	
Pressure Sensor	276-6793	CATERPILLAR	
Pressure Sensor	320-3060	CATERPILLAR	
Pressure Sensor	278-5273 274-6720	CATERPILLAR	

Description	OEM No.	Application	Picture
Pressure Sensor	296-8060	CATERPILLAR	
Pressure Sensor	320-3063	CATERPILLAR	
Pressure Sensor	161-9926	CATERPILLAR	
Pressure Sensor	330-6719	CATERPILLAR	
Pressure Sensor	320-3061	CATERPILLAR	
Pressure Sensor	434-3436	CATERPILLAR	
Pressure Sensor	239-3478	CATERPILLAR	
Pressure Sensor	161-9930 111-2350	CATERPILLAR	

Description	OEM No.	Application	Picture
Pressure Sensor	291-1581	CATERPILLAR	
Pressure Sensor	161-9932	CATERPILLAR	
Pressure Sensor	221-8859	CATERPILLAR	
Pressure Sensor	167-1709 140-3540	CATERPILLAR	
Pressure Sensor	114-5333 236-6923 293-0740	CATERPILLAR	
Pressure Sensor	103-6092	CATERPILLAR	
Pressure Sensor	163-8530	CATERPILLAR	
Pressure Sensor	304-5666	CATERPILLAR	

Description	OEM No.	Application	Picture
Pressure Sensor	216-3448	CATERPILLAR	
Pressure Sensor	183-4760	CATERPILLAR	
Pressure Sensor	167-3466	CATERPILLAR	
Pressure Sensor	163-8492	CATERPILLAR	
Pressure Sensor	163-8523	CATERPILLAR	
Pressure Sensor	163-8516	CATERPILLAR	
Pressure Sensor	163-8512	CATERPILLAR	
Pressure Sensor	309-5768	CATERPILLAR	

Description	OEM No.	Application	Picture
Pressure Sensor	309-5795	CATERPILLAR	
Pressure Sensor	6T-4949	CATERPILLAR	
Pressure Switch	173-7252	CATERPILLAR	
Pressure Switch	131-9203	CATERPILLAR	
Pressure Sensor	149-6371	CATERPILLAR	
Pressure Switch	227-6744	CATERPILLAR	
Pressure Switch	275-1253	CATERPILLAR	
Pressure Switch	297-1140	CATERPILLAR	
Pressure Switch	309-5769	CATERPILLAR	

Description	OEM No.	Application	Picture
Pressure Switch	106-0179	CATERPILLAR	
Pressure Switch	119-9985	CATERPILLAR	
Pressure Switch	170-9335	CATERPILLAR	
Pressure Switch	3E-6455	CATERPILLAR	
Pressure Switch	9X-4276	CAT	
Pressure Switch	3E-2026	CATERPILLAR	
Pressure Sensor	533-2245	CATERPILLAR	
Pressure Sensor	164-3692	CATERPILLAR	
Pressure Switch	440-0257	CATERPILLAR	

Description	OEM No.	Application	Picture
Pressure Switch	160-2445	CATERPILLAR	
Pressure Switch	198-1302	CATERPILLAR	
Pressure Sensor	110-1168	CATERPILLAR	
Differential Pressure Sensor	266-0136	CATERPILLAR	
Pressure Switch	171-7570	CATERPILLAR	



Description	OEM No.	Application	Picture
Temperature Sensor	238-0112	CATERPILLAR	
Temperature Sensor	235-1790 169-5326 149-4910	CATERPILLAR	
Temperature Sensor	256-6454	CATERPILLAR	
Temperature Sensor	367-0593	CATERPILLAR	
Temperature Sensor	235-8747	CATERPILLAR	
Temperature Sensor	268-4360 216-3436	CATERPILLAR	
Temperature Sensor	173-7527	CATERPILLAR	
Temperature Sensor	341-3600	CATERPILLAR	
Temperature Sensor	264-4297 130-9811 197-8391	CATERPILLAR	

Description	OEM No.	Application	Picture
Temperature Sensor	256-6453	CATERPILLAR	
Temperature Sensor	51-7578	CATERPILLAR	
Temperature Sensor	342-2924	CATERPILLAR	
Temperature Sensor	135-2336	CATERPILLAR	
Temperature Sensor	394-4837	CATERPILLAR	
Temperature Sensor	102-2240	CATERPILLAR	
Temperature Sensor	106-0735	CATERPILLAR	
Temperature Sensor	118-7226	CATERPILLAR	

Description	OEM No.	Application	Picture
Temperature Sensor	131-0427	CATERPILLAR	
Temperature Sensor	145-7028	CATERPILLAR	
Temperature Sensor	3E5370	CATERPILLAR	
Temperature Sensor	297-9314	CATERPILLAR	
Temperature Sensor	134-2252	CATERPILLAR	
Temperature Sensor	278-5307	CATERPILLAR	
Temperature Sensor	4I-5394	CATERPILLAR	
Temperature Sensor	196-7975	CATERPILLAR	

Description	OEM No.	Application	Picture
Temperature Sensor	244-3106 175-3070	CATERPILLAR	
Temperature Sensor	278-5272	CATERPILLAR	
Temperature Sensor	3E8700	CATERPILLAR	
Temperature Sensor	191-6587	CATERPILLAR	
Temperature Sensor	102-0050	CATERPILLAR	
Temperature Sensor	107-8618	CATERPILLAR	
Temperature Sensor	361-6576	CATERPILLAR	
Temperature Sensor	195-2150	CATERPILLAR	

Description	OEM No.	Application	Picture
Temperature Sensor	2W-8915	CATERPILLAR	
Temperature Sensor	339-8822	CATERPILLAR	
Temperature Sensor	415-2432	CAT	
Temperature Sensor	415-2433	CAT	
Exhaust Gas Temperature Sensor	383-2989	CATERPILLAR	
Exhaust Gas Temperature Sensor	383-2982	CATERPILLAR	



Description	OEM No.	Application	Picture
Coolant Level Sensor	165-6634	CATERPILLAR	
Coolant Level Sensor	430-9449	CATERPILLAR	
Coolant Level Sensor	239-9957	CATERPILLAR	
Level Sensor	382-2001	CATERPILLAR	
Level Sensor	423-6434	CATERPILLAR	
Level Sensor	178-2335	CATERPILLAR	
Level Sensor	418-6597 123-2993 172-8660 144-2813	CATERPILLAR	
Level Sensor	263-5792	CATERPILLAR	

Description	OEM No.	Application	Picture
Camshaft Position Sensor	245-4630 119-4142 169-3300 109-7195 236-6221	CATERPILLAR	
Camshaft Position Sensor	238-0120	CATERPILLAR	
Position Sensor	279-9828	CATERPILLAR	
Position Sensor	201-6617	CATERPILLAR	
Position Sensor	279-9829	CATERPILLAR	
Position Sensor	201-6615 194-5338	CATERPILLAR	
Position Sensor	188-7511	CATERPILLAR	
Position Sensor	201-6616	CATERPILLAR	

Description	OEM No.	Application	Picture
Position Sensor	311-3858	CATERPILLAR	
Position Sensor	191-8304	CATERPILLAR	
Position Sensor	194-5340	CATERPILLAR	
Position Sensor	191-8303	CATERPILLAR	
Position Sensor	191-8305	CATERPILLAR	
Position Sensor	189-9801	CATERPILLAR	
Position Sensor	319-6491 183-4584	CATERPILLAR	
Speed Sensor	358-2399	CATERPILLAR	

Description	OEM No.	Application	Picture
Speed Sensor	384-3888	CATERPILLAR	
Speed Sensor	238-4676	CATERPILLAR	



Description	OEM No.	Application	Picture
Position Sensor	318-1181 189-5746	CATERPILLAR	
Speed Sensor	266-1478	CATERPILLAR	
Position Sensor	324-4131	CATERPILLAR	
Speed Sensor	3E7886	CATERPILLAR	
Speed Sensor	266-1466 204-7949 176-1602	CATERPILLAR	
Speed Sensor	258-4521	CATERPILLAR	
Speed Sensor	266-1467 160-2443	CATERPILLAR	
Speed Sensor	266-1477	CATERPILLAR	
Speed Sensor	266-1473	CATERPILLAR	

Description	OEM No.	Application	Picture
Speed Sensor	183-8597	CATERPILLAR	
Speed Sensor	196-1185	CATERPILLAR	
Speed Sensor	290-5792	CATERPILLAR	
Speed Sensor	122-8863	CATERPILLAR	
Speed Sensor	318-1179	CATERPILLAR	
Speed Sensor	264-0148	CATERPILLAR	
Speed Sensor	318-1178 3E8848	CATERPILLAR	
Speed Sensor	125-2966	CATERPILLAR	
Speed Sensor	189-5746	CATERPILLAR	

Description	OEM No.	Application	Picture
NOx Sensor	441-5128 539-0118	CATERPILLAR	
NOx Sensor	441-5127	CATERPILLAR	





**CALL ONE OF OUR QUALIFIED SALES
REPRESENTATIVES TODAY
TO FIND OUT MORE**

011 5684215

QUOTES@CAPIPARTS.CO.ZA

WWW.CAPIPARTS.CO.ZA